





Manual Instruções / Manual de instrucciones/ Instructions Manual/ Mode d'emploi Mesa de Trabalho / Mesa de trabajo / working table / Table de travail



*Só nos modelos com prateleira /
/ Sólo en modelos con estante /
Only on models with shelf /
Uniquement sur les modèles
avec étagère*







*Só nos modelos sem prateleira /
/ Sólo en modelos sin estante /
Only on models without a shelf /
Uniquement sur les modèles
sans étagère*



x12
Parafuso / Tornillo / Screw / Vis
Sextavado / Hexágono / Hexagon /
Hexagone M6x40mm

Legenda /Subtítulo /legend/ Légende	Peças / Piezas / parts / pièces	Quant.
1	Tampo / La encimera /table top / dessus de table	1
2	Prateleira (opcional)/ Estante (opcional) /shelf (optional) / Étagère (facultatif)	1
3	Pernas / patas / legs / Les jambes	4
4	Parafuso / Tornillo / Screw / Vis Sextavado / Hexágono / Hexagon / Hexagone Exterior / outsider / Extérieur M6x40	12
5	Travessas inferiores lateral (opcional) / Barras transversales inferiores laterales (opcional) / Side lower crossbars (optional)/ Traverses latérales inférieures (facultatif)	2
6	Travessa inferior trás (opcional) / Rayo inferior trasero (opcional) / Rear lower beam (optional) / Faisceau inférieur arrière (facultatif)	1
7	Parafuso / Tornillo / Screw / Vis Sextavado / Hexágono / Hexagon / Hexagone Exterior / outsider / Extérieur M8x20	6





Modelos com prateleira / Modelos con estante / Models with shelf / Modèles avec étagère



x12

Parafuso / Tornillo / Screw / Vis
Sextavado / Hexágono / Hexagon /
Hexagone M6x40mm

Modelos sem prateleira / Modelos sin estante / Models without a shelf / Modèles sans étagère



x6

Parafuso / Tornillo / Screw / Vis
Sextavado / Hexágono / Hexagon /
Hexagone M8x20mm